

Outdoor Retractable Banner Stand Instructions



Spare Parts List



The base



Base feet

Slider Locking knob



Support pole

Graphic holder


Assemble Instruction




1. Open the graphic holder, remove end caps, loosen all screws



5. Open the end caps on the base. Tear off the leading paper on the PVC.




9. Install the two sliders into the groove, and make it vertical alignment with the roll up groove.



13. Insert the trinodal pole into the hole on the base.




2. Put the graphic into the graphic holder.




6. Stick the graphic on the leading paper.



10. Hold the roll up base, rotate the locking knob by 90 degree.




14. Pull up the graphic and put the graphic holder onto groove on the top of support pole.




3. Press the graphic holder tightly.



7. Press the PVC with one hand, and pull out the lock pin with another hand.




11.




15. Pull the other graphic up.




4. Set up the end cap on the graphic holder tightly, tighten all screws.



8. Roll the graphic into the base smoothly.



12. Link up the trinodal pole as a whole pole, like the picture.



16. Insert the other graphic holder onto the hole as the same way.