


# Pop-up A-Frame Banner User Instructions

## The Kit consists of:


1. The banner and its fiberglass frame
2. Velcro distancing straps (for large-size banners)
3. Metal triangle loops
4. Metal pegs
5. Carry bag



## Setup:

**First, make sure no person, pet or inanimate object is standing or sitting within a seven foot radius when you open the carry bag. (The banner can pop-out and strike someone, or become damaged itself.)**

Carefully unzip the carry bag, grabbing the folded banner frame with a free hand lest it suddenly pop-out. Remove the banner from the bag. Still holding the banner, allow it to open and pop up. Attach the Velcro distancing straps. (If your banner is 107.48" x 53.54", cross the Velcro straps, as in the first illustration hereunder; if not, place them straight across as in the second illustration.) When outdoors on a golf course or on the sidelines of a natural football field, you can use the pegs (enclosed in the transparent pouch on the front of the carry bag) to secure the banner. Simply place the pegs in the metal triangle loops and press them into the ground.



If you are setting the banner up outdoors on a hard artificial surface (sidewalk, driveway, Astro turf, etc), you can secure the banner with a water bag filled with water or sand, or by using plastic bottles filled with the same.

Indoors, the banner needn't be secured.

## Take Down:

Pull the pegs from the ground (or remove water bag/plastic bottles). Unfasten the Velcro distancing straps, then follow the illustration below.

