



## Prize Game – Battery Operated LED Lights

### Included:

- One (1) 50 LED Battery Operated 5mm Wide Angle Light Strand- 3D batteries (included) per strand.

### Installation Instructions:

1. Carefully remove the game from packaging.
2. Open the battery box cover insert 3D batteries (included) per strand. Follow diagram in battery box for proper orientation. (Do not mix old and new batteries; do not mix alkaline, standard (carbon-zinc) or re-chargeable batteries (nickel-cadmium) batteries.
3. Close battery box cover.
4. Set battery box switch to desired mode:
  - On- Steady: lights are constantly on.
  - On- Twinkle: lights are on constantly with twinkling effect.
  - On- Glistening: lights are on constantly with glistening effect.
  - Timer- Steady: The lights will stay lit for 6 hours and then switch off for 18 hours. The lights will turn on every day at the same time as originally set and stay on for 6 hours each time. \* For example: If you want the lights to turn on every day at 5pm you need to turn the power switch to the timer at 5pm. Lights will turn on every day at 5pm and stay lit until 11pm.
  - Timer- Twinkle: The lights will stay lit with twinkling effect for 6 hours and then switch off after 18 hours. The lights will turn on every day at the same time as originally set and stay on for 6 hours each time. \* For example: If you want the lights to turn on every day at 5pm you need to turn the power switch to timer at 5pm. The lights will then turn on every day at 5pm and stay lit until 11pm.
  - Timer- Glisten: The lights will stay lit with glistening effect for 6 hours and then switch off after 18 hours. The lights will turn on every day at the same time as originally set and stay on for 6 hours each time. \* For example: If you want the lights to turn on every day at 5pm you need to turn the power switch to timer at 5pm. The lights will then turn on every day at 5pm and stay lit until 11pm.
  - Off- Lights are off.
5. Place in desired position.

### Care Instructions:

- If lights become dusty or dirty, clean with a dry cloth. Do not use detergent as it may discolor the product.
- If lights start to dim, replace batteries. Please note these are LED lights and they are not replaceable.
- Remove batteries before storing.
- Store in cool dry location.

### Battery Information and Disposal:

- Do not dispose batteries in fire.
- For best results, do not mix old and new batteries; do not mix alkaline, standard (carbon-zinc) or rechargeable (nickel-cadmium) batteries.
- For best results, use alkaline batteries.
- Install only new batteries of the same type in your product.
- Failure to insert batteries in correct polarity, as indicated in the battery compartment, may shorten the life of the batteries or cause batteries to leak.
- Improper handling/disposal of batteries may cause batteries to explode or leak.
- Batteries should be recycled or disposed of as per state and local guidelines.