




**DISPLAYS2GO**  
CONNECTING PEOPLE & BRANDS WITH THE WORLD



**OUTDOOR  
SIDEWALK  
SIGN WITH  
WATER-FILLED  
BASE**

**User Manual**

SKUs: PS1536BLK, PS1528BLK, PS1540BLK

# PARTS LIST






Scan QR code  
to visit product  
page



## PART


## QUANTITY

- A: Water-Fill Base..... 1
- B: Poster Frame..... 1
- C: Wingnut Screw..... 2




1. Insert signage frame into base.
2. Flip unit onto its side, then insert wingnut screw with washer and nut through the holes on the bottom of the base.

If you have any questions regarding our products, please visit us at [www.displays2go.com](http://www.displays2go.com) or contact Displays2go customer service at 844-221-3388.



3. Snap frame open and remove the poster cover from the frame.




4. Insert desired poster into frame, then replace the poster cover. Snap the frame closed.



5. Move unit to desired location, then fill base with either water or sand.

NOTE: Empty base before storing or moving again.



*Enjoy your new sidewalk sign!*

CONTACT INFORMATION:  
[www.displays2go.com](http://www.displays2go.com)  
PHONE: 844-221-3388