






Quick Fabric Instructions

1. Take out the display from the tote.

2. Place the hardware banner side up on the floor and pull the frame in both directions to expand the display.

3. Continue to pull the expandable frame outwards.

4. Fully extend the frame until it lays flat and the banner is pulled taut.

5. Lock the frame into place by connecting the top and bottom hooks together throughout the hardware.


6. The top and bottom hooks should easily latch together. If the hooks do not line up, pivot the hooks until they can connect.

6.



7. Your Quick Fabric Display is assembled. Stand the frame upright to display.

7.

