

TALLBOY Banner Replacement Instructions

1. Pull banner all the way out until glossy leader is showing.

2. Place pin back into base to keep banner from retracting.

****Note:** Pin will only go in part way.
Release banner slightly until pin goes in all the way

3. Where the banner meets the glossy leader, remove banner and clean off glue residue.

4. Attach new banner to glossy leader using double-sided tape. Make sure the banner is perfectly straight or the artwork will crinkle when retracted.

5. To attach the top bar, use the provided allen wrench to loosen screws along entire bar. Remove old graphic and slide new graphic into channel, then tighten each screw.

