

DISPLAYS2GO

Instruction Sheet For WC1CD



Unfolded D/C




Fold inner flap in



Fold sides up and in locking tab into slot on bottom



Sides locked in




Fold front flaps inward



Sides and front locked in



Fold back downward and bend backward on perf



Folded display should look like above