











ASSEMBLY INSTRUCTIONS

WCBB SERIES

PARTS LIST	QTY	A	B
A. COUNTER BOX	1		
B. HEADER CARD	1		

INSTRUCTIONS

<p>1. UNFOLD COUNTER BOX AND SQUARE UP. FOLD 3 FLAPS AT BOTTOM INWARD AS SHOWN.</p> 	<p>2. FOLD IN LAST FLAP. INSERT TAB INTO THE MIDDLE SLOT.</p> 	<p>3. FLIP THE COUNTER BOX UP AND LET THE BOTTOM OF THE BOX SIT ON THE SURFACE.</p> 
<p>4. FOLD IN 2 SIDE FLAPS INWARD.</p> 	<p>5. FOLD THE BACK LID DOWN AND CLOSE THE TOP OF THE BOX.</p> 	<p>6. LOCK THE TOP LID BY INSERTING THE TAB INTO THE CORRESPONDING SLOT.</p> 
<p>7. THE BOX ASSEMBLY IS DONE.</p> 	<p>8. INSERT THE HEADER CARD INTO THE SLOT AT THE FRONT TOP EDGE.</p> 	<p>9. THE CARDBOARD BALLOT BOX IS READY.</p> 