





ASSEMBLY INSTRUCTIONS

WCBB SERIES

PARTS LIST	QTY	A	B
A. COUNTER BOX	1		
B. HEADER CARD	1		

INSTRUCTIONS

1. UNFOLD COUNTER BOX AND SQUARE UP. FOLD 3 FLAPS AT BOTTOM INWARD AS SHOWN. 	2. FOLD IN LAST FLAP. INSERT TAB INTO THE MIDDLE SLOT. 	3. FLIP THE COUNTER BOX UP AND LET THE BOTTOM OF THE BOX SIT ON THE SURFACE. 
4. FOLD IN 2 SIDE FLAPS INWARD. 	5. FOLD THE BACK LID DOWN AND CLOSE THE TOP OF THE BOX. 	6. LOCK THE TOP LID BY INSERTING THE TAB INTO THE CORRESPONDING SLOT. 
7. THE BOX ASSEMBLY IS DONE. 	8. INSERT THE HEADER CARD INTO THE SLOT AT THE FRONT TOP EDGE. 	9. THE CARDBOARD BALLOT BOX IS READY. 