


LAYOUT SHEET

It is always a good idea to have a plan before you begin.
Make copies of this page and use to design your signs.



WO/WO
WRITE ON/WASH OFF

**WO/WO™ Sidewalk Sign
USER GUIDE**



Joseph Struhl Company, Inc.
195 Atlantic Ave., PO Box N, Garden City Park, NY 11040
1-800-552-0023 • 516-741-3660 • Fax 516-741-742-3617
www.magicmaster.com



Swinger WO/WO™ Sidewalk Sign

USER GUIDE

1. Assemble sign following directions.
 2. Shake markers well, press tip on clean sheet of paper to charge tip with ink and test marker on scrap paper. Read marker instructions.
 3. Lay sign face on flat surface and decorate sign using markers. **Allow to dry.**
 4. Decorate second side of sign face with same or different message. **Allow to dry.**
 5. Attach decorated sign face to sign following sign directions and display. Do not decorate sign face while on sign.
 6. Use Windex or ammonia based window cleaner to remove old message before starting new message.
- ***DO NOT use dry erase or permanent markers on WO/WO™ sign face – they will not come off. Use only Posterman markers as supplied with sign.***

HELPFUL HINTS

- Layout sign in advance, using copies of layout sheet provided to ensure message fits and looks good. Large and simple messages have the highest impact.
- Try to keep message brief and large for maximum impact. Try different messages on each side for more interest.
- Remember, bigger and bolder graphics make for more effective signs.
- Use colors, decorations and graphics for more interest.
- Change message, colors and layout frequently to maintain interest.
- See sign instruction sheet for high wind and transport hints.

LAYOUT SHEET 