

WSFM416PB Assembly Instructions:

* PLEASE CONFIRM ALL PARTS SHOWN OR NOTED ARE PRESENT BEFORE STARTING. DO NOT DISCARD PACKING.

- Parts:** (1) Base
(1) Wire Frame
(1) Bearing Assembly (2 washers / ball bearing)
(1) Header Clip
(2) Poles (1 w/ flange) ; (1 w/ male side)
(2) Wire Collars (do not need)

Assembly:

Step 1: Place the base on the floor and insert pole with flange into base until completely seated (flange side facing up).



Step 2: Slide bearing assembly onto pole until it is seated on the flange.



Step 3: Slide male side of second pole into the top end of the flanged pole.



Step 4: Slide wire frame onto assembled poles.



Step 5: Place header clip on top of the assembled poles.

