

XB2471M4 Assembly Instructions



1
Put the frame underneath the base.



2
Hang the connector on the backing.



3
Connect the connector to the base.



4
Unlock the clamp to adjust the height of the stand.



5
Insert the arms into the pole.



6
Simply hook the grommets of the banner to the chrome knob.



7
Be sure to fill the base with either water or sand for added weight.