WMSWD4WWH
4-Way Slatwall Pinwheel Fixture
Assembly Instructions

How to Assemble Fixture's Base

Tools Required:
- Rubber Mallet
- Phillips screw driver

Tools Included:
- Allen Wrench

Base Kit Hardware (C-J) listed to the right

Base Kit Contents:
A. (1) Spinner Base Top (assembled)
B. (4) Kick Base parts w/ pre-drilled holes
Base Kit Hardware shown in photo at left
C. (12) Camlocks
D. (12) Camlock Pins
E. (16) Panhead Screws
F. (4) Dowel Pins (4Way)
(8) Dowel PIns (Cube)
GI. (4) Casters
H. (1) Assembly Instructions



Step 1 (Assemble the 4 kick base parts)
- Start by installing the Camlock pins into the pre-drilled holes with the Phillips screwdriver.
- Next, install the Camlocks by tapping them into position with the mallet.
- Match the kicks with the same lengths parallel to each other & lock them with the Camlocks.
- Tip - Tilt the Phillips screwdriver slightly upwards to lock the Camlocks.

Step 2 (Assemble the kick base to the spinner base)
- Start by installing the CamLock pins into the pre-drilled holes of the spinner base.
- Set the kick base onto the spinner base and fasten together with the CamLocks.
- Tip - If you do not want to utilize the spinner base option, install a screw through the bottom of the base panel into the top panel (taking care not to puncture through the top panel). This will stabilize the spinner component of the base unit.

Step 3 (Install casters) the casters are provided / installation is optional
- Install optional casters by positioning the caster into each of the 4 corners.
- Using the pan head screws, attach the casters through the pre-drilled holes on the inside corners of the kick base.
- Tip - get all 4 screws started before doing the final tightening for easier alignments.

Step 4 (Install 4 wooden dowel pins into base top)
- Install the 4 wooden dowel pins into the pre-drilled holes on the base top.
- The spinner base unit is now ready to install the display panels.

How to Assemble Fixture's Wings



Tools and Hardware Required (supplied with base kit hardware)

(1) Allen Wrench
(12) Confirmat Screws
(12) Screw Caps

Tools - Optional
Rubber mallet

4 Way Wing Kit Contents

A. (4) Wing Panels
B. (1) Assembly Instructions

Step 1 (Assemble the 4 Way display panels onto base)

Make sure the 4 wooden dowel pins are inserted into the base top.
*Tip - the rubber mallet can be used to seat the wooden dowel pins fully.

Step 2 (Assemble 4 Way display panels onto base)

Start by installing two panels together onto the dowel pins. Locate the holes on the bottoms of the panels and set them onto the pins. Attach the panels together with the confirmat screws. ***Note: It is helpful to use two people at this step.**

Once the first two panels are together, you can install the remaining panels to complete the unit.

*Tip - Do not fully tighten all the screws until all the panels are in place. Once all the wing panels are together and in place, final tighten the screws.

Step 3 (Adhere the decorative screw caps to cover the screw heads)

Peel the decorative screw caps to expose the sticky back, and carefully center and cover the screw heads.