


Folding LCD Ceiling Mount



**CAUTION: DO NOT EXCEED
RATED LISTED WEIGHT. SERIOUS
INJURY OR PROPERTY DAMAGE
MAY OCCUR!**



ISSUED: MAY, 2013


NOTE: Read the entire instruction manual before you start installation and assembly.

⚠ WARNING

- Do not begin the installation until you have read and understood all the instructions and warnings contained in this installation sheet. If you have any questions regarding any of the instructions or warnings, please contact your local distributor.
- This mounting bracket was designed to be installed and utilised **ONLY** as specified in this manual. Improper installation of this product may cause damage or serious injury.
- This product should only be installed by someone with good mechanical ability who has basic building experience and fully understands this manual.
- Make sure that the supporting surface will safely support the combined weight of the equipment and all attached hardware and components.
- Always use an assistant or mechanical lifting equipment to safely lift and position the equipment.
- Tighten screws firmly, but do not over tighten. Over tightening can cause damage to the items, This greatly reduces their holding power.
- This product is intended for indoor use only. Using this product outdoors could lead to product failure and personal injury.

Component Checklist

IMPORTANT: Ensure that you have received all parts according to the component checklist prior to installation. If any parts are missing or faulty, telephone your local distributor for a replacement.



ceiling mount (x1)
A



4mm Allen key (x1)
B



6mm Allen key (x1)
C

Package M



M4x14 (x4)
M-A



M5x14 (x4)
M-B



M6x14 (x4)
M-C



M8x20 (x4)
M-D



D5 washer (x4)
M-E



D8 washer (x4)
M-F



small spacer (x8)
M-G

Package W



ST6.3x55 (x4)
W-A




concrete anchor (x4)
W-B




D6 washer (x2)
W-C

1. Separating the VESA Plate








Use a proper Allen key to loosen the screws in order to separate the VESA plate from the ceiling mount.

2. Opening the Mount






Open the mount for installing. Press the ceiling plate down, then lift it up till fully open.

3a. For Wooden Ceiling Mounting





Tighten the screw leaving a 4mm space to ceiling





Align the both holes of ceiling plate to the screws in ceiling and move the ceiling plate until the both screws are seated in upper area of tear-drop mounting holes.





Fix the ceiling plate using the two other screws and then tighten all screws.



⚠ WARNING

- Installers are responsible to provide hardware for other types of mounting situations.
- Installers must verify that the supporting surface will safely support the combined weight of the equipment and all attached hardware and components.


3b. For Solid Brick and Concrete Mounting




Mark the exact location of mounting holes




Drill pilot holes




Screw the screws into the ceiling





Tighten the screw leaving a 4mm space to ceiling.





Align the both holes of ceiling plate to the screws in ceiling and move the ceiling plate until the both screws are seated in upper area of tear-drop mounting holes.








Fix the ceiling plate using the two other screws and then tighten all screws.




⚠ WARNING

Installers must verify that the supporting surface will safely support the combined weight of the equipment and all attached hardware and components.

4. Installing the VESA Plate




or



Note: Choose the appropriate screws, washers and spacers (if necessary) according to the type of screen. Screw the VESA plate onto the display.


⚠ **Tighten all screws but do not over tighten.**

5. Hooking the Display onto the Ceiling Mount




Install the screws to fix the ceiling mount and VESA plate together tightly.


6. Adjustment




Loosen screws (but not remove) and adjust the display to desired height as needed, then tighten screws.



7. Adjustment



Adjust to the desired position.



For saving the space, you can fold the display by pushing the display back until it fits in place.

Maintenance

- Check that the bracket is secure and safe to use at regular intervals (at least every three months).
- Please contact your distributor if you have any questions.