



MSHWL1, MSHWL5 & MSHWL10 - Wall-Mount Instructions


Each rack pocket has a wire divider that can be used to divide each larger, single pocket into smaller, double pockets. This flexibility allows for many combinations of larger format literature (i.e. magazines) and smaller literature (i.e. brochures). Each rack includes one longer wire divider for the top pocket and multiple (depending on the pocket quantity) smaller dividers



①



Cutaway
Side View




1) Each wire divider can be removed or adjusted to allow for larger pockets simply by pulling up on the divider to separate it from the front wire frame of the pocket.

2) After the divider is separated from the pocket, rotate it 90° so that the divider stem on the back of the rack is facing down.


3) At this point, you can choose to lay the wire divider down vertically inside the back of the pocket, or you can remove the divider completely by pulling the stem through the front of the hole.

* NOTE: To re-attach the wire dividers to the pockets, simply perform the steps in reverse order.


②



Cutaway
Side View



③



Cutaway
Side View

