

# Wall-Mounted Swing-Open Frame

Assembly Instructions (V2.1)



**DISPLAYS2GO**  
CONNECTING PEOPLE & BRANDS WITH THE WORLD

**! NOTE:** Two people may be required to install large format swing frames.

**Tools required:** Level, Pencil, Drill, Phillips Head Screwdriver.

## STEP 1.

Mount wood Z-Bar to the wall at desired height using level. Mark and drill holes. Secure using wall anchors and screws provided.



## STEP 2.

Hang swing frame centered over wood Z-bar.

## STEP 3.

Open frame door by lifting Gravity Lock. Then mark lower hanging bracket holes with a pencil. Close frame door. While closing, lift Gravity Lock with finger and release over Stoppers to secure in locked position.

## STEP 4.


Use wall anchors where necessary. Drill holes into the wall at marked locations and insert wall anchors.

## STEP 5.

Slide Gravity Lock up with your finger and open frame door.

## STEP 6.

Insert two screws through the bottom hanging bracket and secure into wall anchors. Tighten with phillips head screwdriver.



## TO CLOSE DOOR,

Slide Gravity Lock up, and release to catch Stoppers and secure the Swingframe door.

If your swing frame has a side plunge lock, simply align the door with lock and press lock stem down to lock.

## TO INSERT POSTER,

Remove liner from adhesive tapes in the corners of the backing board, then place poster and remove and change as needed. Posters can also be inserted with other light adhesives, thumb tacks or scotch tape.

If you have any questions regarding our products, please visit us at [www.displays2go.com](http://www.displays2go.com) or contact Displays2go customer service at 844-221-3388.